

Instructions for the Revolver Inlay Kit



The materials used in this kit are Gray dyed Basswood, Colobolo, Alternate Ivory, Curly Maple and a small 1/2" piece of sterling silver wire.

We'll start by sliding the brass tube into the maple barrel. This will help align the pieces as the kit is being assembled. Insert the pieces in numerical order starting with the #1 the barrel. Secure the pieces as you go with the supplied elastic bands. 2 grips are included with every kit so you have the option of using either a Cocobolo or an alternative Ivory grip.

Remove the brass tube and permanently secure the pieces by flooding thin CA glue over all the seams. Once the thin CA has completely cured we're going to glue in the brass tube. Scuff up the tube with 100G sandpaper before gluing. I prefer 2-part epoxy to glue the brass tube in place. Center the brass tube so that the revolver will be centered when the barrel is trimmed.

Once all glue has cured, sand the ends flush to the brass tube (don't use a barrel trimmer) and mount on the lathe for turning and finishing.

