

Basic Instructions for the Kokopelli Pen Inlay Kit



This inlay kit is available with an all black background or a multicolored

background. The assembly

procedures are identical for both kits. We're going to secure all pieces with the supplied elastic bands around the brass tube. Start by scuffing up the tube with some sandpaper. Secure the kokopelli figure (#16) to the brass tube with an elastic band. Slide the figure up and over the top of the tube to allow you to fit piece #6 in next. Slide the assembly back and centered on the tube. Secure the rest of the pieces with elastic bands in any order. Once they're all in position, shift them around a bit to eliminate gaps. Any slight visible gaps can be filled at this time with black CA glue if necessary.

Flood all seams with thin CA. Sand both ends flush to the brass tube and mount on the lathe for final turning and finishing.

